


MeasumaX

MX-600 Series - LINEAR SCALES



L0 = Effective measuring length of scale