
9.2 PARTS LIST OF IKMP 1,2 MODEL

Assembly No	Part Identification	Assembly No	Part Identification
1	Body	31	Motor Gearbox
2	Protection Cover	32	Platform
3	Lower Shaft	33	Connection Bolts
4	Upper Shaft	34	Nut
5	Roll	35	Main Shaft Ring
6	Pin	36	Bolt
7	Rings	37	Nut
8	Nut	38	Gearbox Cover
9	Inner Bushing	39	Gear Box Connection Bolts
10	Inner Bushing Part	40	Nut
11	Protection Cover Connection	41	
12	Bolts M6	42	
13	Bolts M6	43	
14	Side Fastener Wheel	44	
15	Side Fastener	45	
16	Shaft Hand Wheel Nut	46	
17	Shaft Hand Wheel	47	
18	Shaft Hand Wheel	48	
19	Inner Bushing Bolts	49	
20	Nut	50	
21	Greasing Bolt	51	
22	Bolt	52	
23	Nut	53	
24	Bolt	54	
25	Nut	55	
26	Gear	56	
27	Ring	57	
28	Gear	58	
29	Gear	59	
30	Gear	60	

IKMP MOTORISED SWAGING MACHINE PART LIST

